Assembly Instructions for HART HD Mini Trampoline

You will require the following items to assemble each leg of the trampoline.



Step 1 Place the spring washer over the bolt.



Step 2 Place this bolt and washer inside silver spacer



Step 3Place these inside the leg attachment facing as in photos below





Step 4 Place the leg with the bolt into the trampoline leg attachments and tighten with allen key.





Step 5Place cap over tightened end and bang into place with a hammer (Photo 8 & 9)



