



2-555 HART Electronic Start Pistol

Starting Pistol Contents

1. One electronic pistol.
2. One communication cable that can be connected to amplifiers.
3. One screwdriver.
4. One padded storage case.



Product Functions

SOUND: Starting pistol, siren, whistle.

LIGHT: Flash that goes off when the trigger is pulled so that timekeepers can start their devices accordingly.

Product Features

1. 3 in 1 Function:
 - Starting Pistol for Track and Field.
 - Whistle for team sports.
 - Siren for swimming.
2. Can be connected to a race clock (not included) for accurate recording of times.
3. Padded storage case that helps protect the starting pistol when transporting and not in use.
4. Uses 3 x 1.5V AA Alkaline Batteries (not included). This is approximately 2,000 uses of the electronic starting pistol.



WARNING

To prevent fire or electronic shock, do not expose this unit to rain or moisture.



2-555 HART Electronic Start Pistol

Steps for Safe Operation

1. Load 3 x 1.5V AA Alkaline batteries in the battery chamber. See image 1 and 2.
2. Connect the AUX output (pistol) to AUX port of a PA system with the communication cable. See image 3.
3. Switch to sound mode (icon). The power light will turn on. See image
4. Select sound choice (starting pistol, whistle or siren) See image 5.
5. If the flash light is needed for a timekeeper, slide the lightning bolt to sound and light mode. When 'CHARGED' lights up, the pistol is ready for use (both sound and light functions).
6. False start – pull the trigger after the race has started for a double sound effect. You must wait until 'CHARGED' lights up before using again.
7. To connect the starting pistol to a timing device, select the AUX output port of the pistol and AUX port of the timing device with a stereo cable. See Image 6.

