

# **Operation Manual**

Sport Timer with alarm, chronograph, 1/100 sec, lap & split control.

### **Features**

- 1. Hour, Minute, Second & Day of the week.
- 2. Month & Date.
- 3. Chronograph with 1/100 second, with lap/Split control.
- 4. 4 year calendar.
- 5. Beep, Beep alarm with chime & snooze.
- 6. 30 second correction for synchronization.
- 7. 12/24 hour display for user's option.
- 8. Maximum counting: 23 hours, 59 minutes, 9 seconds.

### **Switch Control**


Normal readout: Hour, Minute, Second & Day of the week.

- 1. Press and hold #1 to see Month/Date
- 2. Press and hold #2 to see Alarm Time
- 3. Press #3 to see Mode control for chronograph function
- 4. Then press #3 to set Alarm set mode
- 5. Again press #3 to set Normal Time set mode
- 6. Again press #3 to see Normal Time readout

## **Setting Operation**

#### **Normal Time**

- Press #3, 3 times to get normal time setting mode.
  The 'seconds' will start flashing. Press #1 to set the seconds
- 2. Press #2 to see "Minutes flashing", press #1 to advance Minutes
- 3. Press #2 to see "Hours" flashing, press #1 to advance Hours
- 4. Press #2 to see "Date" flashing, press #1 to advance Date



46-132



- 5. Press #2 to see "Month" flashing, press #1 to advance month
- 6. Press #2 to see "Day of week" flashing, press #1 to advance Day of Week
- 7. Lastly, press #3 once to return to **normal time readout.**

### **12/24 Hour Selection**

While setting "Hour" 12/24 hour readout may be obtained by turn around cycle. I.e. AM/PM in 12 hour format and "H" in 24 hour format.

### **Alarm Time**

- 1. Press #3, twice to get the alarm time "**Hours**" to start flashing, press #1 to advance
- 2. Press #2, once to get alarm time "**Minute**" to start flashing, press #1 to advance
- 3. Lastly, press #3 once to return to normal time readout

# Chronograph

- 1. Press #3 to get into the "Chronograph" mode, by pressing #1, you can now operate the start or stop function on any counting event.
- 2. During a counting, press #2 will enter the watch into lap time mode, meaning that 1 portion of the counting is registered on the display while the counting is still going on in the background.
- 3. Press #2 will get you to the current counting.

### **Alarm Function**

- 1. The function of the alarm can be armed or disarmed by pressing and holding #2 then pressing #1 together.
- 2. When alarm is on, it will display a bell on the upper right corner of the display.
- 3. When the alarm bells on, and the normal time approaches the alarm time, the alarm will sound.
- 4. The alarm will stop itself after 60 seconds, or can be silenced by pressing #1. In either case, the alarm will sound again the same time the next day.

46-132



### **Chime**

- 1. When pressing and holding #2, by pressing #3 can turn on or turn off the chime function.
- 2. When the chime is on, the flags (abbreviated Days on the display) will show on the display.

### **Snooze Function**

When alarm "beep, beep" is on, pressing #1 will enter the watch into a snooze function, it means that the alarm will sound again after 5 minutes unless it is disabled by pressing #2.

### **Battery**

For replacement battery use 1 × LR44, 1.5V

46-132

Phone: 1300 764 719 | 2/26 Scouts Crossing Road Brendale QLD 4500